Accessories for Referees and Scoreboards

Starting revolver.

Art. 3078



Starting revolver cal.380 - 9 mm.k loaded with blanks.

Warnings:

- Keep the gun out of the reach of children.
- Make sure that the gun is discharged before handling it.
- Keep the gun at a safe distance while shooting.
- Do not shoot with empty gun.
- It is recommended to clean and lubricate it after use or periodically, and before starting to shoot after a long period of inactivity.

Vivisport Srl
Via Piave, 43
31016 Cordignano TV
Italia

mail: info@vivisport.it
tel: +39 0438 582316
tel: +39 0438 582318

www.vivisport.it

© Vivisport Srl | 25.11.2026 19:22